



Dementia and Auditory Hallucination Simulator Class Pack

Quick Start Guide

The Dementia and Auditory Hallucination Simulator is used during scenarios to simulate dementia and auditory hallucinations.



Product includes:

- 4 MP3 players
 - Auditory hallucination track
 - Dementia track
- 4 headphones
- Charging cord
- Storage case
- 1-year limited warranty



MP3 player parts identification:

- | | |
|----------------------|----------------------|
| A. Power switch | E. Play/pause button |
| B. Headphone jack | F. Volume controls |
| C. USB charging port | G. Skip track |
| D. Micro SD slot | |



Instructions:

Charging

1. Plug the charging cord into a power block or USB charging port
2. Plug the mini USB into the MP3 player

Note: The power switch needs to be in the ON position in order to charge

Playing Tracks

1. Plug the headphones into the headphone port on the MP3 player
2. Set the power switch of the MP3 player to on, then press play
3. Select the correct track by using the skip track button if needed
 - Dementia track: muffled talking sounds
 - Auditory hallucination track: people talking over one another
4. Set the power switch of the MP3 player to off when finished

Additional help and information

Online Product Support

We're here to help! Our online Product Support features video tutorials, downloadable documents, frequently asked questions and product notices, all of which make it easy for you to get support for products, software and more, day or night. Find our online product support area here: <https://www.realityworks.com/knowledge-base/>

Online Store

Supplies, accessories, select simulators, curriculum and more are available for purchase from our online store 24 hours a day! Find our online store here: <https://www.realityworks.com>